


DL580 User Manual

QuickSpecs

HP ProLiant DL580 Generation 1

Overview



Front View:

1. Quick Removal Access Panel
2. Six Hot Plug Redundant Fans Standard on all models
3. Front accessible Processor and memory drawer
4. Support for up to four Quad-Core Intel® Xeon® Processors
5. Support for up to 16 Small Form-Factor (SFF) SAS or Serial ATA (SATA) drives
6. One front video port
7. Two front accessible USB 2.0 ports
8. Front Panel LED Display and Power Button
9. Half-height tape bay
10. Quick release levers for fast server access
11. Slimline Drive (DVD Drive standard)
12. Slide-out Systems Insight Display
13. Universal Tool-less "Snap In" Sliding Rail Solution
14. Server Lifting Handles
15. 4U (7" Height) Rack Form Factor
16. Up to eleven Available PCI Express/PCI-X Internal Expansion Slots. Eight Standard: (4) full length PCI-E x8, (1) full length PCI-E x4 and (2) half length PCI-E x4 slots. Optional Expansion for up to (3) PCI-X or (3) PCI-E x8
17. Hot Plug Redundant Power Supplies (two standard with 2P Models, requires four for redundancy)

Rear View:

1. Power supplies (2 ship standard in 2P Models; 4 ship standard in 4P Models)
2. Keyboard port
3. Two USB ports
4. Video port
5. Serial port
6. Integrated Lights-Out 2 port
7. Mouse port
8. PCI-Express or PCI-X option (slots 1-3)
9. PCI-Express slots (slots 4-11)
10. Two Multifunction Gigabit NICs
11. Service tool

At A Glance

The ProLiant DL580 G5 server is an enterprise class, 4 socket server designed for maximum scalability and high availability. Its innovative chassis offers unsurpassed flexibility and serviceability in a versatile, rack-optimized form factor. Based upon the latest industry standard processing, memory, I/O and networking technologies, the ProLiant DL580 G5 provides the highest levels of performance demanded by today's compute intensive applications. Unparalleled high availability features, including hot-plug and redundant components, guarantee maximum uptime. Integrated Lights-Out 2 (iLO2) technology allows remote administration from a standard web-browser without ever having to visit the server. Within the 4U dense form factor, it's highly expandable architecture provides maximum application deployment flexibility with the ability to add PCI-



DA - 12770 Worldwide QuickSpecs — Version 18 — 7.18.2008

Page 1

File Name: DL580 User Manual.pdf

Size: 3554 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 8 May 2019, 21:50 PM

Rating: 4.6/5 from 755 votes.

Status: AVAILABLE

Last checked: 16 Minutes ago!

In order to read or download DL580 User Manual ebook, you need to create a FREE account.

[Download Now!](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with DL580 User Manual . To get started finding DL580 User Manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

DL580 User Manual

Keyboard port 11. Support for up to 8 Small FormFactor SFF SAS, Serial ATA SATA or SSD drives 11. PCIExpress or PCIX option slots 16 12. PCIExpress slots slots 711 13. Server Lifting Handles 13. Overview. Traditionally, missioncritical RAS Reliability, Availability and Serviceability features have been associated with. Page 2 QuickSpecs HP ProLiant DL580 Generation 7 G7. Overview. Whats New More Performance Standard Features. Page 4 QuickSpecs HP ProLiant DL580 Generation 7 G7. Standard Features. Memory Protection Advanced ECC Standard Features Standard Features Standard Features. Internal Storage Devices Diskette Drive None Page 8 QuickSpecs HP ProLiant DL580 Generation 7 G7. Power Supply HP 1200W Common Slot Platinum Hot Plug Power Supply. Page 9 QuickSpecs HP ProLiant DL580 Generation 7 G7. HP Insight management HP Insight Foundation Managing the growing number of. Page 10 QuickSpecs HP ProLiant DL580 Generation 7 G7. Security Power on password Optional Features. HP Insight management HP Insight Control HP Insight Control, a product. Page 12 QuickSpecs HP ProLiant DL580 Generation 7 G7. Optional Features. Solutions The ProLiant DL580 G7 server is an enterprise class, 4. Page 13 QuickSpecs HP ProLiant DL580 Generation 7 G7. Optional Features Also included are the HP Unified Parallel. Page 14 Service and Support QuickSpecs HP ProLiant DL580 Generation 7 G7. Service and Support. Service and Support HP Technology Services for Industry Standard Servers. Page 15 QuickSpecs HP ProLiant DL580 Generation 7 G7. Service and Support Page 16 Preconfigured Models QuickSpecs HP ProLiant DL580 Generation 7 G7. Preconfigured Models. Page 17 QuickSpecs HP ProLiant DL580 Generation 7 G7. Base Models. Page 18 Configuration Information Factory Integrated Models QuickSpecs HP ProLiant DL580 Generation 7 G7. Configuration Information Factory Integrated Models. NOTE This section lists some of the. Page 19 QuickSpecs HP ProLiant DL580 Generation 7 G7. <http://fiberglasssupplydepot.com/userfiles/canon-irc3080i-owners-manual.xml>

- **dl580 g7 user manual, dl580 gen9 user manual, 1.0, dl580 g7 user manual, dl580 gen9 user manual.**

Page 20 QuickSpecs HP ProLiant DL580 Generation 7 G7. Configuration Information Factory Integrated Models Page 21 QuickSpecs HP ProLiant DL580 Generation 7 G7. Step 3 Choose Additional Factory Integratable Options. Page 22 Core Options QuickSpecs HP ProLiant DL580 Generation 7 G7. Core Options. NOTE Some options may not be integrated at the factory. To. Page 23 QuickSpecs HP ProLiant DL580 Generation 7 G7. Core Options Core Options. HP Optical Drives NOTE Optical drives are ejectable. Core Options Page 26 QuickSpecs HP ProLiant DL580 Generation 7 G7. HP Networking Gigabit Ethernet Adapters Page 27 QuickSpecs HP ProLiant DL580 Generation 7 G7. HP Power Supplies NOTE Prior to making a power supply selection. Page 28 Additional Options QuickSpecs HP ProLiant DL580 Generation 7 G7. Additional Options. NOTE Some options may not be integrated at the factory. To. Page 29 QuickSpecs HP ProLiant DL580 Generation 7 G7. Additional Options Page 30 QuickSpecs HP ProLiant DL580 Generation 7 G7. Additional Options Page 31 QuickSpecs HP ProLiant DL580 Generation 7 G7. HP Security HP Trusted Platform Module Option 488069B21 Additional Options Page 33 QuickSpecs HP ProLiant DL580 Generation 7 G7. HP Tape Backup NOTE For the complete range of tape drives. Page 34 QuickSpecs HP ProLiant DL580 Generation 7 G7. HP Disk Backup NOTE For the complete range of D2D Backup. Page 35 QuickSpecs HP ProLiant DL580 Generation 7 G7. HP Disk Storage Systems MSA SAN Storage Arrays Additional Options Page 37 QuickSpecs HP ProLiant DL580 Generation 7 G7. HP Intelligent Power iPDU Core Units. Distribution Units iPDU HP 4.9kVA. Page 38 QuickSpecs HP ProLiant DL580 Generation 7 G7. Additional Options Page 39 QuickSpecs HP ProLiant DL580 Generation 7

G7. HP Care Pack Services Hardware Services Onsite ServiceMemory. HP. Page 41 QuickSpecs HP ProLiant DL580 Generation 7 G7. Memory. Memory Cartridge population guidelines. This server contains 8 memory cartridge slots

in.<http://www.centerplac.com.br/datamont/userfiles/canon-irc2880i-manual.xml>

Page 42 QuickSpecs HP ProLiant DL580 Generation 7 G7. The DL580 G7 supports 64 DIMMs across four multicore processors. While there. Page 43 QuickSpecs HP ProLiant DL580 Generation 7 G7. MemoryPage 44 Storage QuickSpecs HP ProLiant DL580 Generation 7 G7. StorageDrive SupportPage 45 QuickSpecs HP ProLiant DL580 Generation 7 G7. Storage. Page 46 QuickSpecs HP ProLiant DL580 Generation 7 G7. StorageStorageHP SCSI Tape Drives External HP. Page 48 QuickSpecs HP ProLiant DL580 Generation 7 G7. Page 49 Power Specifications QuickSpecs HP ProLiant DL580 Generation 7 G7. Power Specifications. HP 1200W Common Slot Silver Hot Plug Power Supply Kit. Part. Page 50 Technical Specifications QuickSpecs HP ProLiant DL580 Generation 7 G7. Technical Specifications. Technical SpecificationsThis value may be limited. Page 52 QuickSpecs HP ProLiant DL580 Generation 7 G7. Technical SpecificationsTechnical SpecificationsPage 54 QuickSpecs HP ProLiant DL580 Generation 7 G7. The information contained herein. Optional Expansion for up to 3 PCIX or 3 PCI E x8 Its innovative chassis offers unsurpassed flexibility and serviceability in a versatile, rackoptimized form factor. Unparalleled high availability features, including hotplug and redundant components, guarantee maximum uptime. Integrated LightsOut 2 iLO2 technology allows remote administration from a standard webbrowser without ever having to visit the server. Within the 4U dense form factor, its highly expandable architecture provides maximum application deployment flexibility with the ability to add PCI. Please check your inbox, and if you can't find it, check your spam folder to make sure it didnt end up there. Please also check your spam folder.

D01 2 EN Series EP Series 2 EP7150 ES40 esl9326d EV67 EV68A EVO D300V Evo D300v Series Evo D310 Evo D510 epc EVO M800c EVO M800w EVO M80v EVO N110 evo n150 evo n160 evo n180 EVO N200 evo n400c n410c EVO N410C 2 evo n600c n610c n610v n620c Evo N610c Series evo n800c n800v n800w presario 2800 EVO NOTEBOOK N400c Evo Notebook N800c Evo Notebook N800v Evo Work Station N800W EVO WORKSTATION W8000 EX Series 2 EXS Series Extensa 600 Series Extensa 616 Series Extensa 620 Series Extensa 690 Series Extensa 710 Series PreFailure Warranty and Compaq Service and Support Programs available on a Worldwide basis — Certain restrictions and exclusions apply. Consult the Compaq Customer Support Center at 1 8003451518 for details. Embedded in the chipset design, this feature allows the use of IndustryStandard Registered DIMMs. The auxiliary Disaster recovery Consult the Compaq Customer Support Center at 1800345 Compaq High Voltage The new Compaq Rack. Please check your inbox, and if you can't find it, check your spam folder to make sure it didnt end up there. Please also check your spam folder. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein. Windows Server 2003 is a trademark of Microsoft Corporation. Intel and Xeon are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries. Linux is a U.S. registered trademark of Linus Torvalds. It enables HP to ship replacement parts directly to you so that you can replace them. Using this program, you can replace parts at your own convenience. The specialist will also determine whether you can replace the part. Most instock parts are shipped the very same day you contact HP.

<http://www.familyreunionapp.com/family/events/boss-manual-me-25>

You may be required to send the defective part back to HP, unless otherwise instructed. For information on the warranty service, refer to the HP website . For the North American program, refer to the HP website . In this case either the Original Spare or the Modified Spare may be shipped

which will not affect performance or functionality of the unit. In this case either the Original Spare or the Modified Spare may be shipped which will not affect performance or functionality of the unit. A discharge of static electricity from a finger or other conductor may damage system boards or other static-sensitive devices. This type of damage may reduce the life expectancy of the device. The grounding plug is an important safety feature. Pay particular attention to the plug, electrical outlet, and the point where the cord extends from the server. Operating the server in this manner results in improper airflow and improper cooling that can lead to thermal damage. If you are servicing internal components, remove the access panel. Installing or accessing the following components will not require extending the server from the rack. The sliding rails could pinch your fingers. Portions of the power supply and some internal circuitry remain active until AC power is removed. When the server enters standby power mode, the system power LED changes to amber. For more information, refer to the documentation that ships with the rack mounting option. Operating the server in this manner results in improper airflow and improper cooling that can lead to thermal damage. The QuickFind diagnostic LEDs are cleared when the server is powered off. Be sure that the panel is securely locked into place before powering up the server. Refer to the instructions for each individual option to determine if removing the system cage is necessary. Reinstall the processors and PPMs into the replacement processor module. The processor, heatsink, and retaining clip make up a single assembly.

The system fails to boot if the PPM is missing. Each PPM must be installed in the correct slot for the processor. The system fails to boot if the PPM is missing. The system fails to boot if the corresponding PPM is missing. Do not install any internal drives or BBWC in this server. This option is preferred. Detaching the cable causes any unsaved data in the cache module to be lost. A 1759 POST message appears, stating that valid data was flushed from the cache. This data is now stored on the drives in the recovery server. You can now transfer the drives and controller, if one was used to another server. If the amber LED blinks after 15 seconds, do not remove the cable from the cache module. The cache module is backing up data, and data is lost if the cable is detached. In this case, a POST error message is displayed when the server is powered up, indicating that the battery pack is temporarily disabled. No action is necessary on your part. The internal circuitry automatically recharges the batteries and enables the battery pack. This process might take up to four hours. During this time, the cache module functions properly, but without the performance advantage of the battery pack. When power is restored to the system, an initialization process writes the preserved data to the hard drives. If the amber LED blinks after 15 seconds, do not remove the cable from the cache module. The cache module is backing up data, and data is lost if the cable is detached. If you believe the system board requires replacement, contact HP Technical Support before proceeding. Be respectful, keep it civil and stay on topic. We delete comments that violate our policy, which we encourage you to read. Discussion. HP has designed an ecosystem of RAS functionalities that has raised the bar for the HP ProLiant DL580 G7. HP ProLiant DL360p Gen8 Server User Guide Abstract This document is for the person who installs, administers, and troubleshoots servers and storage systems.

HP assumes you are qualified in the servicing of computer equipment and trained in recognizing hazards in products with hazardous energy levels. August 2013 Edition 5 Part Number 664724005a Final Notes. The HP ProLiant DL580 Gen9 Server is the ideal choice for the mission-critical enterprise, business intelligence, and database applications you rely on to answer these key business challenges. This enterprise-class four-socket 4S x86 server offers rock-solid reliability. Select type and model of the device to download drivers. Comparison of the HP ProLiant DL580 Gen8 Server to the HP ProLiant DL580 G7 Server. 4 health of the individual subsystems and the field-replaceable units FRUs Socket Guide processor mount simplifies industry standard x86 computing. ProLiant is a brand of server computers that was originally developed and marketed by Compaq. HPE in the

manufacturers operating manual, product quickspecs, or the ProLiant DL100 Series Server. ProLiant DL100 Series Server pdf manual download. Also for ProLiant dl120 g6. 1 HP Server ProLiant DL580 G7 manuals and 1 HP ProLiant DL580 G7 PDF instruction from the manufacturer are available for online reading or downloading in PDF without registration on GuidesBase.com. HP ProLiant BL460c User guide HP ProLiant DL580 G2. ProLiant DL580 Generation 5 Server. ProLiant DL580 Server pdf manual download. Also for ProLiant dl580 g5. Please look at the HP HewlettPackard website to download the manual. This document is intended for experienced technicians. HP assumes that you are qualified in servicing of computer equipment, are trained in recognizing hazards in products with hazardous energy levels, and are familiar with weight and stability precautions for rack installations. Part Number 595655005 July 2012 Edition Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

If during the diagnosis period HP or HP service providers or service partners identifies that the repair can be accomplished by the use of a CSR part, HP will ship that part directly to you for replacement. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés. Facultatif Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le La consegna nel giorno stesso o entro quattro ore è offerta con un supplemento di costo solo in alcune zone. In caso di necessità si può richiedere l'assistenza telefonica di un addetto del centro di supporto tecnico HP. Nel materiale fornito con una parte di ricambio CSR, HP specifica se il cliente deve restituire dei componenti. Qualora sia richiesta Weitere Informationen über das HP Customer Self Repair Programm erhalten Sie von Ihrem Servicepartner vor Ort. Informationen über das CSR Programm in Nordamerika finden Sie auf der HP Website unter . Parts Only Warranty Service Garantie En el caso de todas sustituciones que lleve a cabo el cliente, HP se hará cargo de todos los gastos de envío y devolución de componentes y escogerá la empresa de transporte que se utilice para dicho envío. Para obtener más información acerca del programa de Reparaciones del propio cliente de HP, póngase en contacto con su proveedor de servicios local. Si está interesado en el programa para Norteamérica Volgens de bepalingen van de Parts Only garantieservice zal HP kosteloos vervangende onderdelen ter beschikking stellen. Voor de Parts Only garantieservice is vervanging door CS Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão de obra do serviço.

Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes. 1 Mandatory Verplicht. Ask your question here. Provide a clear and comprehensive description of the issue and your question. The more detail you provide for your issue and question, the easier it will be for other Gigaset DL580 owners to properly answer your question. Ask a question This manual comes under the category Phones and has been rated by 5 people with an average of a 7.2. This manual is available in the following languages English. Do you have a question about the Gigaset DL580 or do you need help. Ask your question here Gigaset DL580 specifications ManualSearcher.com ensures that you will find the manual you are looking for in no time. Our database contains more than 1 million PDF manuals from more than 10,000 brands. Every day we add the latest manuals so that you will always find the product you are looking for. It's very simple just type the brand name and the type of product in the search bar and you can instantly view the manual of your choice online for free. ManualSearcher.com If you continue to use this site we will assume that you are happy with it. Read more Ok. Post your question here in this forum. We're committed to dealing with such abuse according to the laws in your country of residence. When you submit a report, we'll investigate it and take the appropriate action. We'll get back to you only if we require additional details or have more information to share. Note that email addresses and full names are not considered private information. Please mention this; Therefore, avoid filling in

personal details. Please enter your email address. This hp dl580 g2 service manual document is intended for experienced service technicians. HpHpProLiantDL580G UsersManual hphpproliantdl580g usersmanual hp pdf Hp ProLiant DL G Users Manual Server Maintenance And Service Guide HP hp dl580 g2 service manual EliteBook G Notebook PC.

Hp ProLiant DL G Manual de hp dl580 g2 service manual Mantenimiento. Hp ProLiant DL G Manual View and Download HP ProLiant DL Generation hp dl580 g2 service manual maintenance and service manual online. ProLiant hp dl580 g2 service manual DL Generation Server pdf manual download. Also for ProLiant dl g2. Sign In Upload Download Share Url of this. HP ProLiant MicroServer HP ProLiant BL BL10e, BL10e G2, BL20p, BL20p G2, BL20p G3, BL20p G4, BL25p, BL25p G2, BL260c G5, BL280c G6, BL2x220c G5, BL2x220c G6, BL2x220c G7, BL30p. HP ProLiant DL Generation Gen8 The HP ProLiant DL Gen Server is an enterprise-grade four socket 4S x server offering breakthrough performance, rock-solid reliability, and compelling consolidation and manageability. HP NetServer to ProLiant Essentials Rapid Deployment Pack installation and startup service NOTE Install and configure Rapid Deployment Pack in a test environment, then deploy a server image to a maximum of systems in View and Download HP DL ProLiant G installation instructions manual online. Quick Deploy Rail System. Also for DL proliant g5, 37u. This Service Manual covers outboards Evinrude ETEC G V 3. Add to Cart HP Diagrams, Schematics and Service Manuals download for free. Including hp ac vtvm, hp laptop service manual, hp laptop service manual, hp laptop service manual, hp laptop service manual, hp ProLiant DL G Ask about Support HP ProLiant DL G Ask about Support HP ProLiant DL G Ask about Support HP ProLiant DL G Ask about Support View and Download HP DL ProLiant G integration notes online. Implementing Microsoft Windows Server Service Pack on HP servers. DL ProLiant G server pdf manual download. HP ProLiant DL580 G7 Server Maintenance and. Service Manuals for Evinrude E TEC G2 outboards 150. HP DL580 ProLiant G4 Installation Instructions. HP ProLiant DL580 G3 Quickspecs. HP ProLiant DL380 G2 Quickspecs. HP PROLIANT DL580 QUICKSPECS Pdf Download. HP ProLiant DL580 Generation 2 Maintenance And.

HP ProLiant DL760 G2 Quickspecs HardDrivesDirect. HP ProLiant DL380 G5 Quickspecs HardDrivesDirect. HP ProLiant DL580 G8 Quickspecs HardDrivesDirect. Free HP Diagrams Schematics Service Manuals. HP ProLiant DL580 G2 End of Life Date. HP ProLiant DL585 G2 Second Generation Opteron. HP EliteBook 840 G2 Notebook PC Manuals HP. HP EliteBook 840 G2 Notebook PC HP x2 210 HP DL585 PROLIANT G2 INTEGRATION NOTES Pdf. HPE End of Life List HPE EOL Dates Park Place. Manual servidores HP ProLiant DL580 JVare Blog. Hp ProLiant DL580 G2 Manuals. This document is intended for experienced service technicians. HP assumes that you are qualified in the servicing of computer equipment, are trained in recognizing hazards in products with hazardous energy levels, and are familiar with weight and stability precautions for rack installations. Part Number 595655 004 April 2011 Edition 4. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service. 2 Optional — Parts for which customer self repair is optional. These parts are also designed for customer self repair. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product. 3 No — Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. Si vous demandez HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés. 2 Optional Facultatif— Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable.

Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio. 2 Optional Opzionali — Parti la cui riparazione da parte del cliente. Se tuttavia il

cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese aggiuntive a seconda del tipo di garanzia previsto per il prodotto. 3 No Non CSR — Alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un “No” nel Catalogo illustrato dei componenti. 1 Mandatory Zwingend — Teile, die im Rahmen des Customer Self Repair Programms ersetzt werden müssen. Wenn Sie diese Teile von HP ersetzen lassen, werden Ihnen die Versand und Arbeitskosten für diesen Service berechnet. 2 Optional Optional — Teile, für die das Customer Self Repair Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen. 3 No Kein — Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Si solicita a HP que realice la sustitución de estos componentes, tendrá. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra “No” en el catálogo ilustrado de componentes. 1 Mandatory Verplicht — Onderdelen waarvoor Customer Self Repair verplicht is.

Als u HP verzoekt deze onderdelen te vervangen, komen de reiskosten en het arbeidsloon voor uw rekening. 2 Optional Optioneel — Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garanteservice voor het product. 3 No Nee — Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto. 3 No Nenhuma — Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca “No” No, no catálogo de peças ilustrado. The HP ProLiant DL580 G7 Server ships with one of two different memory cartridges, which are not interchangeable. Part number 647058 001 has a label that identifies it as an E7 memory cartridge. 1 Mandatory — Parts for which customer self repair is mandatory. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product. 3 No — Some HP parts are not designed for customer self repair. Si vous demandez HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés. 2 Optional Facultatif — Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez.

HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese aggiuntive a seconda del tipo di garanzia previsto per il prodotto. 3 No Non CSR — Alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un “No” nel Catalogo illustrato dei componenti. 1 Mandatory Zwingend — Teile, die im Rahmen des Customer Self Repair Programms ersetzt werden müssen. Wenn Sie diese Teile von HP ersetzen lassen, werden Ihnen die Versand und Arbeitskosten für diesen Service berechnet. 2 Optional Optional — Teile, für die das Customer Self Repair Verfahren optional ist. Si solicita a HP que realice la sustitución de estos componentes, tendrá. Estos componentes también están

no diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto. 3 No No — Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra “No” en el catálogo ilustrado de componentes. 1 Mandatory Verplicht — Onderdelen waarvoor Customer Self Repair verplicht is. Als u HP verzoekt deze onderdelen te vervangen, komen de reiskosten en het arbeidsloon voor uw rekening. 2 Optional Optioneel — Onderdelen waarvoor reparatie door de klant optioneel is.

Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garanteservice voor het product. 3 No Nee — Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto. 3 No Nenhuma — Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca “No” Não, no catálogo de peças ilustrado.

<http://eco-region31.ru/boss-m25-manual>